

## 1) Low-voltage Energy Storage Systems

Battery Brand	Battery Series	Battery Model	Inverter Series				
			ES	EM	SBP	ES G2	SBP G2
GOODWE	SECU-A	SECU-A5.4L	●	●	●	●	●
	Lynx Home U <sup>*1</sup>	LX U5.4-L	●	●	●	●	●
<b>ES/EM/SBP/BP:</b> *1. ARM firmware versions 11 and above are required for compatibility.							
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2
BYD	Battery-Box Pro Series <sup>*1</sup>	-	●	●	●	●	●
	Battery-Box Res Series <sup>*1</sup>	-	●	●	●	●	●
	Battery-Box LV Series <sup>*2</sup>	-	●	●	●	●	●
	Battery-Box Premium LVL <sup>*2</sup>	LVL 15.4	●	●	●	●	●
	Battery-Box Premium LVS Series <sup>*2</sup>	-	●	●	●	●	●
<b>ES/EM/SBP/BP:</b> *1. ARM firmware versions 00 and above are required for compatibility. *2. ARM firmware versions 07 and above are required for compatibility.							
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2
LG	RESU LV Series	RESU 3.3 <sup>*1</sup>	●	●		●	●
		RESU 6.5 <sup>*1</sup>	●	●	●	●	●
		RESU 10 <sup>*1</sup>	●	●	●	●	●
		RESU 12 <sup>*2</sup>	●	●	●	●	●
		RESU 13 <sup>*2</sup>	●	●	●	●	●
		RESU 6.4 EX <sup>*1</sup>	●	●	●	●	●
<b>ES/EM/SBP:</b> *1. ARM firmware versions 00 and above are required for compatibility. *2. ARM firmware versions 07 and above are required for compatibility.							
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2
PYLON	US2000 Series <sup>*1</sup>	US2000	●	●	●	●	●
	US3000 Series <sup>*2</sup>	US3000	●	●	●	●	●
	US2000C Series <sup>*1</sup>	US2000C	●	●	●	●	●
	US3000C Series <sup>*2</sup>	US3000C	●	●	●	●	●
	Force L1 Series <sup>*2</sup>	Force-L1	●	●	●	●	●
	Force L2 Series <sup>*2</sup>	Force-L2	●	●	●	●	●
<b>ES/EM/SBP/BP:</b> *1. ARM firmware versions 00 and above are required for compatibility. *2. ARM firmware versions 07 and above are required for compatibility.							

## 2) High-voltage Energy Storage Systems

Battery Brand	Battery Series	Battery Model	Inverter Series			
			ET (5-10kW)*	EH	BT	BH
PYLON	Powercube H1 Series	POWERCUBE-H1-48 <sup>*1</sup>	●	●	●	●
	Force H1 Series <sup>*2</sup>	Force-H1	●	●	●	●
	Force H2 Series <sup>*2</sup>	Force-H2	●	●	●	●
*. Including ET Series: ET PLUS+, ET PLUS+ (16A) <b>ET/EH/BT/BH/EHB:</b> *1. ARM firmware versions 07 and above are required for compatibility. Please note that the nominal voltage of POWERCUBE-H1-48 Series must be within the Battery Voltage Range of GoodWe inverters. Maximum 8 units for EH/BH, and 11 units for ET/BT. *2. ARM firmware versions 14 and above are required for compatibility. Please note that the nominal voltage of FORCE-H1 Series must be within the Battery Voltage Range of GoodWe inverters. At least 5 FORCE-H1 battery modules for ET.						